



SXP Laser Screed Cummins Filter Screen Bulletin

April 2006

Dear Valued Customer,

It has come to our attention that the 3.3L Cummins engine in your SXP Laser Screed has a primary inline filter screen located before or upstream of the fuel pump. The purpose of this filter screen is to protect the primer pump (which is in the top half of the fuel/water separator) from debris. This filter screen is inside of the inner most banjo fitting on the fuel filter housing, typically a Blue fuel line connected to it. This filter should be inspected/cleaned periodically or each time a new fuel filter is installed on your machine.

Some signs that your filter screen is partially blocked or restricted are, engine has poor response, engine runs rough or misfires or engine smokes.

Please refer to the attached pages for more details. These new pages should be added to your SXP owner's manual in the operator's/service section.

If you have any questions, please feel free to contact our customer support department at 906.482.7252 Option 4 and one of our agents will assist you.